

## STP Optional Characteristic Configuration Commands

## Table of Contents

Chapter 1 STP Optional Characteristic Configuration Commands.....	1
1.1 STP Optional Characteristic Configuration Commands.....	1
1.1.1 spanning-tree portfast.....	1
1.1.2 spanning-tree bpduguard.....	2
1.1.3 spanning-tree bpdufilter.....	3
1.1.4 spanning-tree uplinkfast.....	4
1.1.5 spanning-tree backbonefast.....	5
1.1.6 spanning-tree guard.....	5
1.1.7 spanning-tree loopguard.....	6
1.1.8 spanning-tree loopfast.....	7
1.1.9 spanning-tree fast-aging.....	8
1.1.10 spanning-tree fast-aging flush-fdb.....	9

# Chapter 1 STP Optional Characteristic Configuration Commands

## 1.1 STP Optional Characteristic Configuration Commands

### 1.1.1 spanning-tree portfast

#### Syntax

**spanning-tree portfast** {bpdufilter | bpduguard | default}

**no spanning-tree portfast** {bpdufilter | bpduguard | default}

To configure the portfast attribute in global configuration mode, run `spanning-tree portfast {bpdufilter default | bpduguard default | default}`. To cancel this attribute in global configuration mode, run `no spanning-tree portfast {bpdufilter default | bpduguard default | default}`.

**spanning-tree portfast** [disable]

**no spanning-tree portfast**

To configure the portfast attribute in port configuration mode, run `spanning-tree portfast [disable | trunk ]`. To cancel this attribute in port configuration mode, run `no spanning-tree portfast`.

#### Parameters

Parameters	Description
bpdufilter	Starts the BPDU filtration.
bpduguard	Starts the BPDU protection.
default	Means the default mode.

#### Default Value

This function is not enabled by default.

#### Command Mode

Global, uplink port configuration mode

### Usage Guidelines:

The portfast attribute enables a port in SSTP/PVST mode to promptly enter the forwarding state without state change. This configuration invalidates in RSTP/MSTP mode.

After the portfast attribute is configured, it need be protected through BPDU Guard configuration or BPDU Filter configuration.

### Command Mode

Global or port configuration mode

### Example

The following example shows how to enable the Port Fast attribute in global configuration mode.

```
Switch_config# spanning-tree portfast default
```

The following example shows how to enable the attributes of port g0/1:

```
Switch_config# interface g0/1
```

```
Switch_config_g0/1# spanning-tree portfast
```

## 1.1.2 spanning-tree bpduguard

### Syntax

**spanning-tree bpduguard {disable | enable}**

**no spanning-tree bpduguard**

To configure BPDU Guard, run spanning-tree bpduguard {disable | enable}. To cancel BPDU Guard, run no spanning-tree bpduguard.

### Parameters

None

### Default Value

This function is not enabled by default.

### Command Mode

Interface configuration mode, ONU configuration mode

## Usage Guidelines

In SSTP/PVST mode, if a port that has the BPDU Guard function and the Portfast function configured receives BPDU, this port will be mandatorily shut down. You have to configure the port manually to resume this port. In RSTP/MSTP mode, if a BPDU-Guard-configured port receives BPDU, the port will be set to the Blocking state in a period of time.

## Command Mode

Port configuration mode

## Example

The following example shows how to enable BPDU protection on port g0/1.

```
Switch_config# interface g0/1
Switch_config_g0/1# spanning-tree bpduguard enable
```

### 1.1.3 spanning-tree bpdupfilter

## Syntax

**spanning-tree bpdupfilter {disable | enable}**

**no spanning-tree bpdupfilter**

To configure the BPDU filtration, run **spanning-tree bpdupfilter {disable | enable}**. To cancel the BPDU filtration, run **no spanning-tree bpdupfilter**.

## Parameters

None

## Default Value

This function is not enabled by default.

## Command Mode

Interface configuration mode, ONU configuration mode

## Usage Guidelines:

In SSTP/PVST mode, a port which has the BPDU Filter function and the Port Fast function configured receives BPDU, the BPDU Filter attribute and the Port Fast attribute are automatically shut down. In this case, the port resumes to be a normal port which first enters the listening state, the learning state and then the forwarding state.

This function invalidates in RSTP/MSTP mode.

## Command Mode

Port configuration mode

## Example

The following example shows how to enable BPDU filtration on port g0/1.

```
Switch_config# interface g0/1
```

```
Switch_config_g0/1# spanning-tree bpdufilter enable
```

### 1.1.4 spanning-tree uplinkfast

## Syntax

To configure the Uplink Fast function, run this command. To return to the default setting, use the no form of this command.

**spanning-tree uplinkfast**

**no spanning-tree uplinkfast**

## Parameters

None

## Default Value

This function is not enabled by default.

## Command Mode

Global configuration mode

## Usage Guidelines

The Uplink Fast function validates only in SSTP/PVST mode.

## Example

The following example shows how to enable the Uplink Fast attribute.

```
Switch_config# spanning-tree uplinkfast
```

Switch\_config#

### 1.1.5 spanning-tree backbonefast

#### Syntax

To configure the backbonefast function, run `spanning-tree backbonefast`. To cancel the backbonefast function, run `no spanning-tree backbonefast`.

**spanning-tree backbonefast**

**no spanning-tree backbonefast**

#### Parameters

None

#### Default Value

This function is not enabled by default.

#### Usage Guidelines

The backbonefast function validates only in SSTP/PVST mode.

#### Command Mode

Global configuration mode

#### Example

The following example shows how to enable the backbonefast function:

```
Switch_config# spanning-tree backbonefast
```

```
Switch_config#
```

### 1.1.6 spanning-tree guard

#### Syntax

To configure the Port Guard function, run `spanning-tree guard {loop | none | root}`. To cancel this function, run `no spanning-tree guard`.

**spanning-tree guard {loop | none | root}**

**no spanning-tree guard**

## Parameters

Parameters	Description
<i>loop</i>	Guard loop.
<i>none</i>	Guard none.
<i>root</i>	Guard root

## Default Value

This protection function is not enabled.

## Command Mode

Port configuration mode, ONU configuration mode

## Usage Guidelines

The Root Guard attribute can prevent a port from serving as a root port after it receives a higher-priority BPDU.

The Loop Guard attribute can protect a port after it changes from a root port or an alternate port to a designated port. This function can prevent a port from generating a loop when the port cannot receive BPDU continuously.

## Example

The following example shows how to prevent port g0/1 from being the root:

```
Switch_config_g0/1# spanning-tree guard root
Switch_config_g0/1#
```

### 1.1.7 spanning-tree loopguard

## Syntax

To configure the guard loop in global configuration mode, run **spanning-tree loopguard default**. To cancel the guard loop in global configuration mode, run **no spanning-tree loopguard default**.

**spanning-tree loopguard default**

**no spanning-tree loopguard default**



**Parameters**

None

**Default Value**

None

**Usage Guidelines**

None

**Command Mode**

Global configuration mode

**Example**

The following example shows how to enable the loopguard function.

```
Switch_config# spanning-tree loopguard default
```

### 1.1.8 spanning-tree loopfast

**Syntax**

Port, ONU configuration mode, and global configuration mode:

To enable Loop Fast in global configuration mode, run **spanning-tree loopfast**. To return to the default setting, use the **no** form of this command.

**spanning-tree loopfast**

**no spanning-tree loopfast**

To disable the Loop Fast attribute, run the following command.

**spanning-tree loopfast disable**

**Parameters**

None

**Default Value**

None

## Command Mode

Global configuration mode, interface configuration mode and ONU configuration mode

## Usage Guidelines

**Please configure this command under the guide of technical engineers.**

## Example

The following example shows how to enable loopfast in global configuration mode and disable the function on port G0/1.

```
Switch_config#spanning-tree loopfast
```

```
Switch_config# interface g0/1
```

```
Switch_config_g0/1#spanning-tree loopfast disable
```

```
Switch_config_g0/1#exit
```

### 1.1.9 spanning-tree fast-aging

#### Syntax

**spanning-tree fast-aging**

**no spanning-tree fast-aging**

The two commands above are used to enable or disable the fast aging mechanism of the address table.

**spanning-tree fast-aging protection**

**no spanning-tree fast-aging protection**

The two commands above are used to enable or disable the protection of fast aging of the address table.

**spanning-tree fast-aging protection time *value***

**no spanning-tree fast-aging protection time**

The two commands above are used to configure the time of aging protection of the address table.

#### Parameters

Parameters	Description
------------	-------------

<i>value</i>	Stands for the aging protection time. 10-60 seconds (15 seconds by default)
--------------	---

### Default Value

Fast aging is enabled by default. However protection is not enabled by default.

### Usage Guidelines

None

### Command Mode

Global configuration mode

### Example

The following example shows how to enable fast aging protection and set the protection time to 30 seconds.

```
Switch_config#spanning-tree fast-aging protection
```

```
Switch_config#spanning-tree fast-aging protection time 30
```

## 1.1.10 spanning-tree fast-aging flush-fdb

### Syntax

To enable FDB-Flush, run the following command. To disable FDB-Flush, use the no form of this command.

**spanning-tree fast-aging flush-fdb**

**no spanning-tree fast-aging flush-fdb**

### Parameters

None

### Default Value

FDB-Flush is enabled by default.

### Command Mode

Global configuration mode

## Usage Guidelines

**Please configure this command under the guide of technical engineers.**

FDB-Flush is independent of fast aging. FDB-Flush can be configured while **no spanning-tree fast-aging** is configured. But fast aging protection function has no effect on FDB-Flush.

## Command Mode

Global configuration mode

## Example

The following example shows how to disable fast aging and enable FDB-Flush.

```
Switch_config#no spanning-tree fast-aging
```

```
Switch_config#spanning-tree fast-aging flush-fdb
```